



OMNI DUAL SHOCK TUBE INITIATOR

INSTRUCTIONS FOR USE

1. Check to ensure that the safety pin is inserted correctly.
2. Pull the spring loaded firing pins to the extreme rearward position.
3. Cut the shock tube squarely to expose a clean open end.
4. Remove the clamp block located at the front of the device to expose the primer chamber. Remove the primer holders.
5. Insert a standard shotgun primer (available at gun shops & sporting good stores) into the chamber and replace the primer holders along with clamp block.
6. Insert the shock tube into the front of the device where two holes are located. A slight twisting motion may be helpful while inserting. Insert until you can no longer make a further insertion.
7. Pull the shock tube out around ¼". Then, tighten the clamp until you can no longer pull the shock tube out.
8. Fire the device by simply removing the safety pin and pressing on the lever(s).
9. After firing remove the shock tube and the expended primer(s). The primer(s) can usually be removed by tapping on a hard surface. Check the bore for obstructions.
10. Replace the safety pin after firing.

SAFETY PRECAUTIONS

1. Before firing, the device should be held at arms length in a safe direction, Treat this device as you would a firearm.
2. DO wear ear and eye protection while firing.
3. DO NOT carry the device while loaded. *

MAINTENANCE

1. Clean and lubricate the device as you would a firearm. DO NOT let solvents come in contact with your primers as it will ruin them. To clean use any 3n1 oil.